



ASSEMBLY INSTRUCTIONS

IN THE CONTAINER YOU WILL FIND THE FOLLOWING COMPONENTS:

2 X SIDES (A) & (B)	24 X WOODEN DOWELS
1 X BOTTOM (C)	8 X SHELVES SUPPORTS
1 X TOP (C)	2 X CLIP ON HINGES
2 X SHELVES	2 X BASE PLATES
3 X FIXING CLEATS (E)	4 X WALL FIXING SCREWS AND PLUGS
1 X WHITE MASONITE BACK (G)	

TOOLS REQUIRED:

SMALL HAMMER; DRILL & 6MM MASONARY DRILL BIT;
PHILIPS SCREW DRIVER

- 1) CHECK ALL COMPONENTS.
- 2) TAP WOODEN DOWELS INTO SIDES (A) & (B) WITH COLD GLUE
- 3) LAY SIDE (A) FLAT ON THE FLOOR
- 4) ATTACH FIXING CLEATS (E), TOP (C) AND BOTTOM (C)
- 5) SLIDE MASONITE BACK (G) INTO GROOVES PROVIDED IN (A) & (B)
WITH WHITE SIDE FACING FRONT
- 6) STAND CUPBOARD UP
- 7) ATTACH SHELF SUPPORTS WHERE REQUIRED
- 8) PLACE SHELF ON SHELF SUPPORT
- 9) DRILL 2 HOLES THROUGH MASONITE AND TOP FIXING CLEAT AND
ATTACH TO WALL WITH FIXING SCREWS AND PLUGS PROVIDED

DOOR FITTING

- 1) SCREW BASE PLATES TO HOLES ON PANELS (A) OR (B)
- 2) SCREW HINGES ON TO DOOR
- 3) CLIP DOOR AND HINGES ON TO BASE PLATES
- 4) ADJUST HINGES TO LEVEL UP DOOR
- 5) MARK DRILL AND FIT HANDLE